

Sony FE-2
Led Flashes error Code

Error Message
LED Code

- 00 No error
- 01 Reserved
- 02 OCP (Over Current Protection)
- 03 Not Used
- 04 No Vertical Sync
- 05 IKR Error at power on
- 06 Ilc bus clock and/or data lines low at power on
- 07 NVM no Ilc bus acknowledge at power on
- 08 Not Used
- 09 Tuner no acknowledge at power on
- 10 Sound Processor Error
- 11 Jungle controller 8 volts error